

## RX 350/500 (Real Gate Spoiler)

1. Trial fit the product to the vehicle and mark the installation position with masking tape or similar.
2. Thoroughly degrease the product mounting surface of the vehicle, peel off a small portion of the release paper from the double-sided tape in fig 1, bend it outward, and temporarily attach it to the vehicle. While checking the overall balance, peel off the release paper and press it down.

Fig.1



Fig.2

