

CROWN SPORT (Rear Gate Spoiler)

1. Refer to fig.2 and temporarily attach the product to the vehicle to check the clearance etc. and if necessary. mark the installation position with masking tape etc.
2. Thoroughly degrease the area of the vehicle where the product will be attached ,then peel off both ends of the release paper from the double- sided tape on the back of the product .fold it to the front of the product.
3. 1.place the product temporarily on temporarily on the area marked in step 1,slowly pull out the release paper from the center of the vehicle in order ,and firmly press the double -sided tape part on the front of the product to attach it to the vehicle.

Fig.1



Fig.2

