

LAND CRUISER 250
(GDJ250W/TRJ250W)
2024/4-

Bonnet Protector

Set up Guide

1. Open the hood of the vehicle and refer to figure 2 to temporarily fit the product to the vehicle to check the clearance ,etc. if necessary ,mark the installation position with masking tape etc.
2. Thoroughly degrease the area of vehicle where the product will be attached, then peel off both ends of the back of the product, fold it to the front of the product, and temporarily secure the product, and temporarily secure the release paper with masking tape or similar.
- 3.1. place the product temporarily on the area marked in step 1, slowly pull out the release paper in order from the center of the vehicle, and firmly press the double-sided tape on the product to attach it to the vehicle.

