

LM500 (Rear Gate Spoiler)

1. Temporarily place the product on the vehicle, check the installation position, and mark the installation position with masking tape or the like.
2. Degrease the vehicle and the spoiler mounting area thoroughly.
3. Apply the supplied “a” to the area shown in Fig. 1.
4. Read the advice on the use of the sealer in the separate sheet carefully and install the spoiler to the vehicle. Secure the spoiler to the vehicle with masking tape and duct tape, and hold it in place until the sealant has fully cured. Hold the sealant until it is fully cured.

Fig.1



Back side of product

Fig.2

