

HARRIER Side Step Ver.2

SET UP GUIDE

1. Remove the original fasteners shown in part A in figure 1. and temporarily fit the product to the vehicle. mark the installation position with masking tape ,etc. and sure there is no interference when opening and closing the door.
2. Figure 2-a shows how to attach the bracket from the mounting bracket hole to the genuine side panel ,temporarily assemble accessory E using accessories C and D mark the hole on the spoiler.
- 3.2 Drill a 3.0mm hole at each of the points marked in figure 2.
4. Thoroughly degrease the product mounting surface of the vehicle .peel off a small portion of the release paper from the double -sided tape in figure 2.bend it outwards and temporarily attach it to the overall balance peel off the release paper from the center of the product outward (remove any remaining release paper first). Remove the remaining release paper and press the product into place.
5. 5. in Figures 1 and 2, fasten parts A together with the original fasteners, and secure part C in Figure 2-a with accessory b. In Figure 2-b, secure part B with the included fasteners and tighten all other parts. Repeat on the other side.

List of included parts;

quantity

A.4×12 tapping screws	2
B.4×16 tapping screws	2
C.M6×15mm trussbolt	2
D.M6 flange nut	2
E..stay	2

