

# HARRIER

## front half spoiler ver.2

### SET UP GUIDE

1. Using accessories c and d, temporarily assemble Product A to the mounting hole (C) in Figure 2-a, referring to Figure 2-a.
2. Trial fit product A to the vehicle, check the installation position , and mark it with masking tape , etc .Trial fit product B ,and mark the installation holes in figure 3 and the small installation hole in accessory e on the vehicle.
3. Drill 3.0mm holes at each of the (6 locations) marked in step 2.
4. Thoroughly degrease the spoiler mounting surface of the bumper ,peel off a small portion of the release paper from the double -sided tape on the back of the product and fold it outward(please peel off any release paper that cannot be pulled out after installation ) ,temporarily assemble the product to the vehicle at the location marked in 2 .while checking the overall balance .peel off the release paper ,press down attach product B and secure it in place with the included accessories.
5. Referring to Figure 2-a ,fasten accessories C and D to accessory A.

#### List of included parts;

	quantity
A.4×12 tapping screws	2
B.4×12 tapping screws	4
C.M6×15mm truss bolt	2
D.M6 flange nut	2
E.stay	2

