

HARRIER Ver2
Rear Under Spoiler
SET UP GUIDE

1. Using accessories B and C, temporarily assemble the small mounting holes (see figure 2-a) of product A into the mounting holes in Figure 2C. Use the (R) marking on the included accessories for the driver`s side and the (L) marking on the passenger`s side.
2. Remove the genuine fasteners that secure the genuine bumper in place (see Figure 2).
3. Trial fit product A to the vehicle, check the installation position and mark it with masking tape ,etc. Trial Fit product B, and mark the vehicle through the mounting hole in Figure 3.
4. Drill 3.0mm holes at each of the 4 locations marked in figure 3.
5. Thoroughly degrease the spoiler mounting surface of the bumper, peel off a small portion ■ of the release paper from the double-sided tape on the back of the product and fold it outward (please peel off any release paper that cannot be pulled out after installation).temporarily assemble the product to the vehicle at the point marked in 3.and while checking the overall balance ,peel off the release paper ,press down ,attach product B ,and secure with accessory A.
6. Referring to Figure 2-a ,fasten accessories B and C to the original fasteners.

List of included parts;	quantity
A. 4×12 ,tapping screws	4
B. M6×15mm truss bolt	2
C. M6 flange nut	2
D. Stay	2

